Dimensions




Model Number

MLV12-54/76b/124/128


Retroreflective sensor with metal connector M12; 5-pin, 90° convertible

Features

- ٠ Robust photoelectric sensor series in a widely used standard housing
- Resistant against noise: reliable operation under all conditions
- Clear and functional display concept for the operating modes
- High level of stability thanks to the ٠ metal housing frame
- Tightly sealed thanks to welded ٠ plastic components
- Suitable for operation at low • temperatures down to -40 °C



Electrical connection




Pinout






(gray)

Indicators/operating means





1	Operating display green			
2	Switch state yellow			
3	Light/dark switch			
4	Sensitivity adjuster			
5	Optical axis emitter			
6	Optical axis receiver			

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com ⁵ PEPPERL+FUCHS 1

Technical data			Accessories
General specifications			OMH-MLV12-HWG
Effective detection range		0 6.5 m	Mounting bracket for series MLV12
Reflector distance		0.01 6.5 m	sensors
Threshold detection range		9 m	OMH-MLV12-HWK
Reference target		H85-2 reflector	Mounting bracket for series MLV12
Light source		LED	sensors
Light type		modulated visible red light , 660 nm	3613013
Polarization filter		yes	OMH-K01
Diameter of the light spot		approx. 170 mm at detection range 6.5 m	dove tail mounting clamp
Angle of divergence		1.5 °	
Ambient light limit			OMH-K02
Continuous light		50000 Lux	dove tail mounting clamp
Modulated light		5000 Lux	
Functional safety related para	meters		ОМН-К03
MTTF _d		1000 a	dove tail mounting clamp
Mission Time (T _M)		20 a	ОМН-06
Diagnostic Coverage (DC)		90 %	Mounting aid for round steel ø 12 mm or
Indicators/operating means			
Operation indicator		LED green, flashes in case of short-circuit	sheet 1.5 mm 3 mm
Function indicator		2 LEDs yellow, light up when light beam is free, flash when falling short of the stability control, off when light beam is interrupted	Other suitable accessories can be found at www.pepperl-fuchs.com
Control elements		rotary switch for light/dark, sensitivity adjuster	
Electrical specifications			
Operating voltage	UB	10 30 V DC	
Ripple		max. 10 %	
No-load supply current	I ₀	max. 40 mA	
Input			
Test input		emitter deactivation at 0 V	
Output			
Switching type		light/dark on switchable	
Signal output		1 push-pull (4 in 1) output, short-circuit protected, reverse polarity protected	
Switching voltage		max. 30 V DC	
Switching current		max. 0.2 A	
Voltage drop	U _d	≤ 2.5 V DC	
Switching frequency	f	1000 Hz	
Response time		0.5 ms	
Conformity			
Product standard		EN 60947-5-2	
Ambient conditions			
Ambient temperature		-40 60 °C (-40 140 °F)	
Storage temperature		-40 75 °C (-40 167 °F)	
Mechanical specifications			
Housing width		41.5 mm	
Housing height		49 mm	
Housing depth		15 mm	
Degree of protection		IP67	
Connection		Metal connector, M12, 5-pin, 90° rotatable	
Material Housing		Frame: nickel plated, die cast zinc,	
		Laterals: glass-fiber reinforced plastic PC	
Optical face		Plastic pane	
Mass		60 g	
Compliance with standards an directives	nd		
Standard conformity			
Shock and impact resistance		IEC / EN 60068. half-sine, 40 g in each X, Y and Z directions	
Vibration resistance		IEC / EN 60068-2-6. Sinus. 10 -150 Hz, 5 g in each X, Y and Z directions	
Approvals and certificates			
Protection class		II, rated voltage \leq 300 V AC with pollution degree 1-2 according to IEC 60664-1	
UL approval		cULus	
CCC approval		CCC approval / marking not required for products rated ≤36 V	


Date of issue: 2019-11-27 115230_eng.xml Release date: 2019-11-27 14:02


2

Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

Curves/Diagrams





Additional Information

Conventional use

The reflex light beam switch contains the emitter and receiver in a single housing. The light from transmitter is beamed back from a reflector to the receiver. If an object interrupts the light beam the switching function is initiated.

Mounting instructions

The sensor can be fastened over the through-holes directly or with a support angle or clamping components (this are not contained in the scope of supply).

The base surface must be flat to avoid distorting the housing during mounting. It is advisable to secure the bolts and screws with washers to prevent misalignment.

Adjustment instructions

Connect the sensor to operating voltage, the LED green lights up constantly.

Mount suitable reflector opposite light beam switch and align roughly.

The exact adjustment takes by swivelling the sensor horizontally and vertically. With optimum light reception the yellow LED lights up constantly. They flash if setting is inexact.

Object detection check

Move the object into the light beam. If the object is recorded, the yellow LED switch off. If it does not switch off, reduce the sensitivity with the potentiometer until the switches off. It should lights up constantly on again when the object is removed.

Lustration

The yellow LED flashes if reception deteriorates (e.g. soiled lenses.)

We recommend that you clean the optical interfaces and check the plug- and screw connections at regular intervals.

115230 eng.xml Date of issue: 2019-11-27 Release date: 2019-11-27 14:02

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com **EPEPPERL+FUCHS**

3